


Soap/Lotion Dispenser Installation:

Tools You May Need




Adjustable wrench

Before Installation


1. Check the package and confirm all parts are included. If any part is missing or damaged, please contact us.
2. Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory.
3. Ensure that you have gathered all the materials needed for installation.
4. Carefully read the installation guide and install this product according to the installation guide.
5. Operate this product by pressing straight down on the pump head. Pressing on the spout could cause damage. (CAUTION)

Cleaning and Maintenance


1. Regular cleaning can prevent soap build up on pump head and body.
2. Use a mild detergent and warm water for cleaning.
3. Do not use any acid, polisher, abrasive or harsh cleaner.
4. Do not leave the cleaner on the fixture longer than necessary.
5. Rinse with clean water and dry with a soft cloth.




1. Unscrew the bottle (A), lock nut (B) and rubber washer (C) from the pump assembly (D).



2. Insert the pump assembly (D) through the mounting hole. Make sure the rubber washer (E) is fitted into the pump base (F).



3. Underneath the countertop, slide rubber washer (C) and lock nut (B) onto the pump assembly (D). Position the pump assembly (D) correctly, fixing the lock nut (B) tightly.



4. Thread the bottle (A) into the pump assembly (D) until secure. (**Note:** Do not overtighten.)