

# Installation Instruction

## Before You Begin


1. Shut off the main water supply.
2. Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory.
3. To avoid the faucet from jamming, DO flush the water pipe before installation.
4. After installation, make sure every joint is safely sealed (NO LEAKAGE).
5. Make sure to connect the hot/cold inlet pipe correctly, if standing in front, hot water pipe connecting to the left and cold water pipe connecting to the right.
6. It is recommended that installation of the product be done by a professional plumber.

## Cleaning & Maintenance

To keep product clean and shiny follow the instruction below.

1. Flush with clean water and dry with soft cloth only.
2. Do not use any detergent, polisher, sane-cloth, or a scraper.
3. Do not use acid detergent.

## Installation



1. Mark the position and drill holes to suit the anchor.
2. Install the anchors and fix the shower valve into the wall. Use the air bubble level on the protective cover to ensure that the valve is straight and level. (**Important:** Flush the water pipes to remove any dirt and debris before installing the valve body.)
3. Wrap Teflon tape around the pipe threads. Connect hot and cold water supply lines and all the in-wall pipes (not included) as desired to the shower valve.
4. Turn on the water supply and open the cartridge. Make sure that no leakage occurs. (**Note:** Because the shower system has a built-in valve, test the water pressure after the pipe connections have been made and before the finished wall material is installed.)
5. Remove the protective cover when the finished wall is completed. Install the escutcheon into the shower valve and press it against the finished wall.
6. Install the handle and diverter knob and tighten set screws with Allen key. Then, put on decorative buttons.
7. Wrap the shower arm threads with Teflon tape. Install the shower arm into the shower outlet through the cover plate. Then, add a rubber washer and attach the shower head to the shower arm.
8. Wrap the tub spout with Teflon tape and install the tub spout to the spout outlet.
8. Wrap the threaded end of supply elbow holder with Teflon tape and install the supply elbow holder into the hand shower outlet.
9. Place rubber washers in both ends of the shower hose. Connect shower hose to the supply elbow holder and the hand shower.
10. Place the hand shower in the supply elbow holder.